



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77817

2001 - 2002

FORD RANGER

OEM BUMPER COVER

GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 15 minutes.

PARTS LIST

1	Speed Grille Insert	1	Instruction Sheet	4	Installation Clips # 71098
1	Got Street Scene Decal	1	Street Scene Emblem	4	Installation Clips # 71095
				1	Speed Grille Care

TOOL LIST

NO TOOLS REQUIRED

1. Insert the Speed Grille insert into the opening in bumper cover.
2. Attach from the back side using the four shorter clips on the top side and the four longer clips on the bottom side.
3. Install the Street Scene Emblem on the grille face. Remove the protective cover.