



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77818
SPEED GRILLE
1998-2000 FORD RANGER
WITH S/S 950-70818
FRONT VAL/BUMPER COVER

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 10 minutes.

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	8	Attaching Clips # 71098
		1	Street Scene Decal	1	Got Street Scene Decal

TOOL LIST	
Safety glasses	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove Speed Grille section from package.
3. Install the Speed Grille section into the valance from the front side.
4. Attach from backside with 8 attaching clips four on top and four on the bottom. **NOTE:** if the clips don't reach, Speed Grille is not push back enough.
5. Make sure Speed Grille section is positioned properly and that the barbs on the clips are locked into the holes in the Speed Grille.

