



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77865

1997 - 2000

TOYOTA

TACOMA

MAIN GRILLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 45 minutes.

PARTS LIST

1	Upper Grille Section	1	Instruction Sheet	24	Attaching Clips # 71099
1	Lower Grille Section	1	Street Scene Emblem	1	Got Street Scene Decal

TOOL LIST

Miss. Hand Tools

1. Remove OEM grille shell from truck.
2. Install Speed Grille inserts into opening.
3. Clip from back side using 12 clips per grille. Use 6 across the top and 6 across the bottom. Clip at the right & left of toyota emblem, at the outer ends and centered between.
4. Install grille shell into truck.
5. Pull Plastic cover off on Street Scene Emblem. And attach Emblem on grille.