

STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	4	Washerhead Phillips Screws
		1	Street Scene Decal		
TOOL LIST					
Long Blade Phillips Head Screwdriver, 5 mm Wrench, 5 mm Socket, 1/4" Drive ratchet					

- 1. Open hood. Remove the OEM grille assemble by removing the four bolts across the top. Save these bolts. If you like you can install the emblem onto the Speed Grille.
- 2. Gently pull the grille forward and remove the fourbolts securing the OEM grille from the bumper cover. This can be achieved with the use of a small ratchet and socket or with and end wrench.
- **3.** Remove the four "J" nuts from the grille carefully. Install the "J" nuts onto the bumper cover with the flat side facing up.
- **4.** Install Speed Grille into opening. Install the four screws thru the holes marked on Speed Grille and screw into the "J" nuts that were installed into the valance in step 3. Do not tighten at this time.
- **5.** Lean Speed Grille back and attach across top with the OEM bolts where marked. Align and tighten with a long blade phillips screwdriver. Reach through top of grille and tighten the four lower screws.