



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-77911

1996-1999 HONDA CIVIC
SPEED GRILLE INSERT

&

GRILLE SHELL

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, preped, or painted are not returnable.

Note: Painting Is Necessary

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 2 Hours.

PARTS LIST					
1	Grille Shell	1	Instruction Sheet	8	Attaching Clips # 71098
1	Speed Grille Insert	1	Street Scene Emblem	1	Got Street Scene Decal

TOOL LIST	
Drill Motor, Drill Bits, Miss. Sockets, Wrenches, Ratchet, Phillips Head Screwdriver, Safety Glasses	

1. Before beginning installation be sure to wear proper eye protection if drilling.
2. The easiest way to remove the grille shell from the vehicle is by removing the complete front valance.
This is easily achieved by opening the hood and removing the four bolts across the top of the grille, the two under the front of the valance opening, and the ones at the lower corners.
3. Remove the remaining screws securing the grille shell to the valance. Remove the speed nuts (Screw Clips) from the OEM grille Shell. Drill holes on the new grille shell and install the speed nuts.
4. Install the Speed Grille insert into the grille shell and secure with four clips across the top and four clips across the bottom. Install the clips with the flat side of clip facing away from grille.
5. Re-install valance and grille assemble into vehicle.

