

## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591

## INSTALLATION INSTRUCTIONS

950-76924 BLACK CHROME 950-77924 SATIN FINISH 950-78924 CHROME FINISH 2008 - 2009 PONTIAC G-8 LOWER SPEED GRILLE INSERTS

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RT Speed Grille Insert	1	Instruction Sheet	8	Grille Mounting Ties (11") Long
1	LT Speed Grille Insert	1	Street Scene Emblem	1	Care For Grilles

TOOL LIST
Drill Motor, 5/64 Drill Bit, Side Cut Pliers

- 1. Pull or pry out the OEM black ABS grille assemble.
- 2. Drill four 5/64 holes as shown in photo below in each assemble.
- 3. Insert the Speed Grille insert into the opening. Fasten to the grille assemble using the mounting ties provided. Insert tie through one of the holes drilled and into the loop of Speed Grille and back into the adjoining drilled hole. On the opposite end do the same but loop around one of the grids.



4. Snap grille assemblies back into fascia.