



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-77728 SATIN FINISH
&
950-78728 CHROME FINISH
SPEED GRILLE
1999 - 2000
FORD LIGHTING
FOR
OEM BUMPER COVER GRILLE

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 20 minutes.

Note: No Drilling Is Required

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	12	Attaching Clips # 71099
		1	Street Scene Emblem	1	Got Street Scene Decal

TOOL LIST	
Safety Glasses, 7mm Socket, Ratchet, Or Phillips Head Screwdriver	

NOTE: Matching top grille is SS part number 950-77718, For ease of installation we recommend raising front of vehicle.

1. Undo the splash apron from bottom side of bumper cover.
2. Remove the nine 7 mm head / phillips head screws attaching the OEM grille to the bumper cover.
3. Install the Speed Grille insert into the opening from the front side of vehicle.
4. Attach from the back side using six clips on the top side and six clips on the bottom side with the flat side facing away from Speed Grille.
5. Re-attach splash shield to bumper cover.

