



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-76768 BLACK CHROME

950-77768 SATIN FINISH

950-78768 CHROME FINISH

2008

FORD SUPER DUTY

SIDE VENT

SPEED GRILLE INSERTS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST

1	Instruction Sheet			1	Right Side Vent Speed Grille Insert
1	Street Scene Emblem			1	Left Side Vent Speed Grille Insert
1	Care For Grilles			4	Self Locking Retaining Rings

TOOL LIST

Door Panel Removal Tool Or Equivalent, Side Cut Pliers
--

1. Pry off the " F-350 " logo off the front fender being careful not to scratch the paint. Pry off the chrome vent. If any of the eight rectangular retainers remain in the body, remove and install on plastic vent before reinstalling.
2. Set the vent up side down on a table or bench. Carefully pry off the retaining clips that attach the plastic vent grids to the chrome frame. Be carefull not to break off the round studs. You can cut the retaining ring with a pair of side cut pliers.
3. Set the Speed Grille over the studs and attach with the new retaining rings provided. A deep small socket works well to install the retaining ring.
4. Re-install the side vent to front fender by first aligning the mounting clips to the holes in fender and then applying pressure to snap into position.

THE SPEED GRILLE™ may be covered by one or more of the following U.S. Patents: D427,119,D425,834,D421,585,D420,961,D420,960,D420,959, and D420,958 may be covered by one or more pending U.S. Patent applications.

12/10/07 SSE 950-76768 & 950-77768 & 950-78768