



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, Ca. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-80226
 CHEVY CAMARO
 2010
 MAIN GRILLE CUT OUT
 STYLE BILLET

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

NOTE:

Check fit all body parts PRIOR to paint. Follow urethane prep instructions before painting. Take your time and pre-fit all pieces so that they will have a tight fit to the body.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE:

We recommend you install Splitter, Air Ducts, and the Grilles at the same time. That way you only have to pull the fascia off one time.

| PARTS LIST | | | | | |
|------------|----------------------|---|---------------------|--|--|
| 1 | Billet Insert | 1 | Instruction Sheet | | |
| 10 | Phillips Head Screws | 1 | Urethane Prep Sheet | | |
| 10 | Tinnerman Nuts | | | | |

| TOOL LIST |
|---|
| 10MM Socket, Ratchet Torx-20, Flat Blade Screwdriver, Phillips Head Screwdriver |

1. Open hood. Then you will need to pull the front fascia off to install the Street Scene Grille Ducts. To do this after opening the hood across top top of fascia you will need to remove the 10MM bolts and 6 push in fasteners. Then there are two more bolts on the bottom of fascia. See photos below.



2. Next on the inside of the wheel well there will be 3 screws on each side. Use a Torx20 to remove. Then pull open splash guard open. There will be one 7MM bolt and 3 more 10MM bolts. You will have to reach in to remove. See photos below



3. Slide off the front fascia but you will have to un-plug the wires for the lights. See photo below.



4. Now unplug the lights and place the front fascia on a soft cover bench. Hold the Street Scene Splitter in place to see where it will be installed. You will need to clean with the 3M Promoter where the two sided tape will be used. Both the Splitter and the bottom of fascia will need to be cleaned.

5. After taking off the fascia you will need to pull off the plastic main grille. See photo below.



6. Now take your grille insert and place in the hole. On the insert you will see 10 mounting holes place the insert where you want it to be installed and drill the mounting holes. Then use the hardware provided.
7. Now you need to place the fascia back on vehicle in reverse order.