



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, CA. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-80513  
2006 - 2008  
DODGE RAM  
4 PIECE INSERT KIT  
4MM BILLET

### INSTALLATION INSTRUCTIONS

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
8	U-Hooks	1	Instruction Sheet	1	Upper Drivers Side Insert
8	Loc Nuts	8	Stop Brackets	1	Lower Drivers Side Insert
				1	Upper Passenger Side Insert
				1	Lower Passenger Side Insert

TOOL LIST	
5/16 Wrench, 5/16 Socket	

1. Set the billet insert into the hole on the grille shell. From the back side connect the u-hooks thru the grille shell and on the stop bars on the insert. One on each side left and right and centered.
2. Next connect the L Stop Brackets the the Loc Nut and snug up.
3. Now you want to center the grille insert in the grille shell the tighten the loc nuts.
4. You will need to do this for a 4 grille inserts.