



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-85731

2010 - 2011

FORD MUSTANG

SSE LOWER BUMPER COVER

3 PC BLACK BILLET

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE: THIS BILLET GRILLE ONLY FITS SSE 950-70790 FRONT FASCIA

PARTS LIST

| | | | | | |
|-------------|---------------|----------|-------------------|----------|----------------------|
| 3 PC | Billet Insert | | Instruction Sheet | 2 | Phillips Head Screws |
| 2 | Hook Bolts | 2 | Nyloc Nuts | 2 | Tinnerman Nuts |

TOOL LIST

Phillips Screwdriver, 3/8" Wrench

1. Place center grille insert into mounting hole hole from the front side.



2. From the back side you need to use the hardware provided use the hook bolt and stop bracket and nyloc nut.



3. On the center grille use the two center bars for mounting. From the back side hook on the bar and then put the stop bracket on then nut.



4. Ready to install the side grille inserts. The two top holes you will use the stock hardware for mounting and one hole at the bottom you will use the hardware provided one screw and one tinnerman nut.



Bottom Mounting
Hole

5. When using the screw and tinnerman nut screw thru mounting hole and into the side of the urethane then on the other side find the screw and put the tinnerman nut on there and tighten.