

## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue Costa Mesa, Ca. 92626 Phone (714) 426-0590 Fax (714) 426-0591 950-77151 SATIN FINISH & 950-78151 CHROME FINISH GMC / SIERRA PICK-UP

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST						
1	Speed Grille Insert	1	Instruction Sheet	14	Installation Clips # 71098	
1	Care For Grilles	1	Street Scene Emblem	2	Tinnerman Nuts # 10 Part # 01000	

TOOL LIST	
10 MM Socket & Ratchet, Flat Blade Screwdriver, Pliers	

- 1. Open hood & remove the four fasteners across the top of the grille shell. Remove the fastener to the grille center.
- 2. Gently pull the grille shell forward to release the fasteners at each corner and the four located on the chrome surround.
- 3. Set the grille shell face down on a covered table or work bench.
- 4. Remove the GMC logo by depressing the four tabs securing it to the grille shell and pulling the logo forward to remove. The GMC logo may be reinstalled on the Speed Grille if desired, To do this cut off the four tabs flush with back of logo. DO NOT remove the two round pins. Set the Speed Grille into grille shell to locate the position of logo. Remove Speed Grille and logo and set face down on bench or table. Two tinnerman nuts have been supplied to fasten the logo to Speed Grille. Place tinnerman nuts on the round pins and tighten to secure logo.
- 5. Install the Speed Grille insert into grille shell guiding it past the chrome edge and over the black ledge. Fasten with the installation clips provided, Use eight across the top and six across the bottom. Refer to photo for location of clips.

## **NOTE: PHOTO ON OTHER SIDE**

- 6. Install the Street Scene Emblem to the grille face at the right hand corner. Remove the protective cover.
- 7. Re-install grille shell into vehicle.

## **BACK SIDE OF GRILLE SHELL**



