



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-15241

2004

CHEVY COLORADO

&

GMC CANYON

ELECTRIC MIRRORS

WITH SIGNAL CONVERSION

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

PARTS LIST

1	RT. Mirror Head	1	LT. Mounting Plate	12	6 MM Nuts
1	LT. Mirror Head	1	Street Scene Emblem		
1	RT Mounting Plate	1	Instruction Sheet		

TOOL LIST

10 MM Socket, Extension, Ratchet, Panel Removal Tool (Optional)

1. Open windows.
2. Remove the mirror trim panel, located behind the mirror and above the door panel by prying the top away from the door. (Use panel removal tool) and pulling up to unhook the bottom.
3. Unplug mirror from connector plug.
4. Remove the three bolts securing mirror to door and remove mirror.
5. Remove the gasket from mirror.
6. Install the mounting plate to mirror head using the nuts provided. Tighten snugly. **DO NOT USE LOCTITE. DO NOT OVER TIGHTEN.**
7. Install the OEM gasket removed in step 5.
8. Install mirror assemble to door. Use three nuts provided and tighten. Plug mirror into harness.
9. Install the trim panel by first inserting the bottom tab into the slot in door and then snapping the top in the hole.



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-15241
CONNECTING
STREET SCENE
SIGNAL® MIRRORS
2004
CHEVY COLORADO
2004
GMC CANYON

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15211	950-25211	950-27241
950-15241	950-25241	950-28245
950-18245	950-26245	

1. Refer to mirror installation instructions and install mirrors.
2. Remove door panels. This can be done by first removing the two phillips head screws located in the armrest. Make sure windows are in **"UP"** position. Remove the armrest by lifting up the backside and pulling back to remove. **Be Careful Not To Break Off The Front Tab.** Remove the phillips screw located behind the door release handle and remove the bezel, secured by the screw. Use a suitable tool and pry the bottom side of door panel from door. Pry the sides from door and lift up to remove. If vehicle is equipped with a tweeter speaker, unplug it from door by reaching in from behind door panel before removing door panel.
3. Run the signal wire down into the door.
4. Remove the access panel on each side of dash board see figures 1 & 2. Pry up at notch with a small screwdriver to remove.

FIGURE 1



FIGURE 2



FIGURE 3

5. Remove the panel below the steering column and the metal shield behind it. See Figure 3



FIGURE 4

6.



Open glove box and pinch sides inward and open glove box to full extend. See Figure 4

7. Pull the rubber boot out between the door and door frame. Guide the signal wire through the exposed hole in the door and out the opening vacated by the rubber boot. Remove any slack in the wire.
8. The rubber boot between the door and vehicle wraps around a plastic connector as it enters the door frame. Separate the boot from the connector. See Figure 5

FIGURE 5



FIGURE 6



9. Use a small screwdriver and depress the top center of the connector, See Figure 6, and pull out the connector from the door frame.
10. Pass the signal wire harness through the rubber boot and remove any slack in the wire.
11. There is a small channel between the wire connector and the plastic connector. See Figure 7. Guide the signal wire through this channel, See Figure 8, and pass the wire into car through the door frame, See Figure 9. Keep the wire flat and DO NOT TWIST wire when passing through the plastic connector.

FIGURE 7

FIGURE 8



FIGURE 9

12. The wire on the passenger side mirror needs to run behind the dash board to the driver side area. Pass wire behind glove box area and over steering column.



13. Using a utility knife separate the red and black wires from both Signal Mirror wire harness. Label the RED wire a each Signal mirror wire harness accordingly (Driver's Side And Passenger Side). Trim the black wires from both harness to length. Strip and twist the black wires together and crimp them to the supplied grounding ring terminal. Pull on the black wire and the grounding ring terminal to make sure the connection is secure. Attach the grounding ring terminal to the grounding bolt near the kick panel area.

14. Remove the Driver's side kick panel by pulling it toward the brake pedal to release the fasteners.

15. Pull the carpet back to expose the metal floor and the rubber gromet in the center. See Figure 10

FIGURE 10

16. With an awl puncture two small holes through the rubber gromet. Push the RED wires through.

17. Raise the vehicle to gain access to the underside running along the frame rail locate the split loom containing the wire harness. Open the split loom and locate the dark green wire. Using a quick splice connector connect the RED wire labeled " Passenger Side "



18. Locate the larger of the two WHITE wires. If you are uncertain of the correct wire. Activate the Driver's Side turn signal and test with a test lamp. Connect the RED wire labeled " Driver's Side " to the white wire using the quick splice connector.

19. Turn on ignition and test signals. If signal mirrors do not operate check splice connector or ground connection.

20. Install all interior parts in reverse order of removal.