



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
 Costa Mesa, CA. 92626
 Phone (714) 426-0590 Fax (714) 426-0591

950-17120
 1988 - 1998 GM CK TRUCKS
 &
 1992-1999 SUBURBAN/TAHOE
 ELECTRIC CAL-Vu MIRROR
 WITH REAR SIGNAL
 & HEATED GLASS
 CONVERSION KIT

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

NOTE: Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

NOTE: Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	2	Foam Rubber Strips

TOOL LIST
Phillips screwdriver, 8mm combination wrench, 10mm combination wrench, door panel clip & trim pad removal tool GM part number : J 38778 or equivalent window crank removal tool GM part J 9886-01 or equivalent, manual windows only.

SECTION 1 88 - 94 GM CK TRUCK

1. Roll down windows and remove armrest screw using phillips screwdriver.
2. If equipped with manual windows, remove window crank with handle removal tool.
3. If equipped with power windows, remove Power Assist Control Panel using the panel removal tool. Lift from the front to detach clips.
4. Remove retaining clips from back of the three switches located on the Control Panel.

- 5 . Remove screw from behind panel and unplug wiring from Control Panel by releasing retaining clips.
- 6 . Using the GM Removal Tool, slide under edge of door panel and lift to pop off clip, move around panel with tool releasing all of the clips. Lift panel upward to remove.
- 7 . Remove nylon clips from inner door and reinstall onto door panel.
- 8 . Remove foam mirror access plug from door.
- 9 . Unplug wire harness connector, then remove stock mirror with 10 mm wrench.
- 10 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using an 8 mm wrench. Install adhesive backed foam rubber strips to mounting plate. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing, then apply strip.
- 11 . Remove gasket from stock mirror plate and install on the Cal-Vu mirror. (some trimming may be necessary for best fit.)
- 12 . Install Cal-Vu mirror using stock hardware, then plug in wire harness connector.
- 13 . Install foam mirror access plug into door.
- 14 . Install door panel by placing window seal portion of panel over door frame the lining clips up with holes. Use the palm of your hand to pop in place.
- 15 . On power windows equipped trucks, plug wiring into control panel, replace screw and pop panel into place. Install armrest screw.

SECTION II 95 - 97 GM CK TRUCK

- 1 . Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
- 2 . Remove foam mirror access plug from door.
- 3 . Unplug wire harness connector, then remove the three mounting 10 mm nuts which fasten the mirror to the door to remove mirrors.
- 4 . Install Cal-Vu mounting plates to mirror heads (nuts provided) using an 8 mm wrench.
- 5 . Install adhesive backed rubber strips to mounting plates. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing , then apply strip.
- 6 . Remove stock gaskets and install on your Cal-Vu mirrors.
- 7 . Install mirrors, tightening nuts fully, then plug in wire harness connector.
- 8 . Replace foam mirror access plug.
- 9 . Install trim piece by sliding the bottom in first and then snapping firmly at the top.



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

CONNECTING STREET SCENE SIGNAL® MIRRORS

1988-1998 CHEV, GMC CK TRUCKS

1992-1999 SUBURBANS, TAHOES

& YUKONS & CREW CAB DUALY'S

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS

950-15110	950-17120	950-18120
950-15120	950-17126	950-20120
950-15126		

1. Install Street Scene Signal ® Mirrors assemblies to doors, following mirror installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehical. If any problems exist, repair before wiring Street Scene Signal ® Mirrors.
3. Remove the kick panels.
4. Run the Red / Black wire from the mirror into the door and thru the door boot. Run the right wire under the dash across to the steering column.
5. Run the left wire in the same way to below the steering column.
6. Remove the phillips head screws securing the panel beneath the steering column. This will expose the bundle of wires.
7. Locate the solid " LIGHT BLUE " wire. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with a test light to verify that flashing turn signal is present. Label that wire as " Driver's Side Turn ". Locate the solid " DARK BLUE " wire and probe with test light. Activate the passenger side turn signal to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
8. Make sure the harnesses are routed securly under the dash and enough slack is left for splicing.
9. Using the Quick Splice connector provided, splice the RED wire from the driver side harness into the " LIGHT BLUE " wire labeled " Driver's Side Turn ". Do not cut any wires when splicing, Splice the Red wire from the passenger side harness into the " DARK BLUE " wire labeled " Passenger Side Turn ".
10. Strip and twist together the ends of the " BLACK " wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal frame work of the vehicle.
11. Activate each turn - signal to verify that the Street Scene Signal ® Mirrors are working. Replace all the lower dash panels removed.
12. Re-install door panels.

1/11/01 Connecting Signal® Mirrors

1988 - 1998 Chevy / GMC CK trucks

1992 - 1999 Suburbans / Tahoes / Yukons & Crew Cab Dually's



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
HEATED MIRROR
CONVERSION KIT**

1988-1998 CHEV/GMC/CK TRUCKS

1992-1999 SUB/TAHOE/YUKON

CREW CABS

Connecting Street Scene Heated Mirror Conversion Kit

Instructions For Part Numbers:

950-16120	950-19120	950-20920
950-17120	950-19920	
950-17920	950-20120	

SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. **Do not mix up**

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel. Drill a 1/2" diameter hole and insert the switch from the front side and install the nut from the backside and tighten.

NOTE: LOCATION OF WIRES ON SWITCH

Top Of Switch: (Marked "Earth") Black wire from four foot power connecting harness.

Center Of Switch: (Marked "Load") Red wires from right & left mirror heaters.

Bottom Of Switch: (Marked "Supply") Red wire from four foot power connecting harness.

Locate a switched 12 volt power supply at the fuse panel (Power goes off when ignition switch is in the " off " position). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. **DO NOT** connect to a constant 12 volt power supply.

3. Remove the right and left kick panels.
4. Run the **Red / Black** wire on the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness through the door and out the hole vacated by the boot. Remove any slack.
5. Pass the wire harness through the rubber boot between the door and the door frame.
6. Guide the wire harness through the door frame and into the vehicle.
7. Do the same on the passenger side. Run the wire across the dash to the left side of the steering column.
8. Connect the **RED** wire from the right and left wire harness to the center pin on the switch using the " **One to Two** " connector.
9. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.