



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING
STREET SCENE
HEATED MIRROR
CONVERSION KIT
1985 - 2001
ASTRO & SAFARI VANS**

Connecting Street Scene Heated Mirror Conversion Kit

Instructions For Part Numbers:		
950-16420	950-17420	950-19440
950-16440	950-17440	950-20440

SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. **Do not mix up**

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel. Drill a 1/2" diameter hole and insert the switch from the front side and install the nut from the back side and tighten.

NOTE: LOCATION OF WIRES ON SWITCH

Top Of Switch: (Marked "Earth") Black wire from four foot power connecting harness.

Center Of Switch: (Marked "Load") Red wires from right & left mirror heaters.

Bottom Of Switch: (Marked "Supply") Red wire from four foot power connecting harness.

Locate a switched 12 volt power supply at the fuse panel (Power goes off when ignition switch is in the " off " position). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. **DO NOT** connect to a constant 12 volt power supply.

3. Remove the kick panels.
4. Run the **Red / Black** wire from the mirror into the door. Pull the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Guide the wire through the rubber boot and into the vehicle. On the right side it may be necessary to move the **ECM** module to pull the wire through. Remove any slack from harness and re-install **ECM**. Replace the rubber boot between the door and door frame.
6. Route the wire harness across the dash to below the steering column. It will be necessary to remove some panels and engine cover.
7. Connect the **RED** wire from the right and left wire harness to the center pin on the switch using the " **One to Two** " connector.
8. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.