



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING  
STREET SCENE  
SIGNAL® MIRRORS  
1997 - 2001  
DODGE DAKOTA  
&  
DURANGO**

### CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15610	950-18620	950-25610
950-15620	950-18629	950-25620
950-17625	950-20620	950-25625
950-17620	950-20629	

1. Install Street Scene Signal® Mirrors assemblies to doors following mirror installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehicle. If any problems exist repair before wiring Street Scene Signal® Mirrors.
3. Run the **RED / BLACK** wire from the mirror into the door. Pull the rubber boot out between the door and door frame. Guide the wire harness through the exposed hole in the door and out the opening vacated by the rubber boot. Remove any slack in the wire harness
4. The rubber boot between the door and vehicle wraps around a plastic connector as it enters the door frame. Use a small pry bar to pull out the connector from the door frame.
5. Separate the rubber boot from the connector.
6. Pass the wire harness through the rubber boot and remove any slack in the wire harness.
7. There is a small channel between the wire guides and plastic connector. Guide the wire harness through this channel and then pass the wire into the truck through the door frame. Remove any slack in the wire harness and stretch the rubber boot back over the plastic connector. Snap the plastic connector back into the door frame.
8. To better access the wire harness coming through the door frame the kick panel needs to be removed.
9. Do the same on the passenger side. Run the wire across the dash over to the driver side area.
10. The vehicle's electrical wiring is located under the dashboard to the left of the brake pedal. Locate the solid **LIGHT GREEN** wire near the top of the wire block. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with the wire tester to verify that flashing turn signal power is present. Label that wire as "**Driver Side Turn**". Locate the solid **LIGHT BROWN** wire near the top of the wire block. Activate the passenger side turn signal and probe the wire with the wire tester to verify that flashing turn signal power is present. Label that wire as "**Passenger Side Turn**".
11. Make sure the harness are routed securely under the dash and enough slack is left for splicing.
12. Splice the **RED** wire from the driver side harness into the solid **LIGHT GREEN** wire previously labeled "**Driver's Side Turn**".
13. Splice the **RED** wire from the passenger side harness into the solid **LIGHT BROWN** wire previously labeled "**Passenger Side Turn**". When attaching wires use the quick splice connectors provided. Do not cut any wires.
14. Strip and twist together the ends of the **BLACK** wire from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal framework of the vehicle.
15. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.