



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

<b>CONNECTING STREET SCENE HEATED MIRROR CONVERSION KIT</b>
1988-1998 CHEV/GMC/CK TRUCKS
1992-1999 SUB/TAHOE/YUKON CREW CABS

## Connecting Street Scene Heated Mirror Conversion Kit

Instructions For Part Numbers:		
<b>950-16120</b>	<b>950-20120</b>	
<b>950-17120</b>	<b>950-26120</b>	
<b>950-19120</b>	<b>950-27120</b>	

### SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. **Do not mix up**

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel. Drill a 1/2" diameter hole and insert the switch from the front side and install the nut from the backside and tighten.

### NOTE: LOCATION OF WIRES ON SWITCH

**Top Of Switch: ( Marked "Earth" ) Black wire from four foot power connecting harness.**

**Center Of Switch: ( Marked "Load" ) Red wires from right & left mirror heaters.**

**Bottom Of Switch: ( Marked "Supply" ) Red wire from four foot power connecting harness.**

Locate a switched 12 volt power supply at the fuse panel ( Power goes off when ignition switch is in the " off " position). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. DO NOT connect to a constant 12 volt power supply.

3. Remove the right and left kick panels.
4. Run the **Red / Black** wire on the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness through the door and out the hole vacated by the boot. Remove any slack.
5. Pass the wire harness through the rubber boot between the door and the door frame.
6. Guide the wire harness through the door frame and into the vehicle.
7. Do the same on the passenger side. Run the wire across the dash to the left side of the steering column.
8. Connect the **RED** wire from the right and left wire harness to the center pin on the switch using the " **One to Two** " connector.
9. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.



**STREET SCENE EQUIPMENT, INC.**

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING  
STREET SCENE  
FRONT & REAR FACE  
SIGNAL® MIRRORS**  
1988-1998 CHEV, GMC CK TRUCKS  
1992-1999 SUBURBANS,TAHOES  
& YUKONS & CREW CAB DUALY'S

**CONNECTING STREET SCENE SIGNAL® MIRRORS**

INSTRUCTIONS FOR PART NUMBERS		
950-15110	950-17126	950-25120
950-15120	950-18120	950-26120
950-15126	950-20120	950-27120
950-17120	950-25110	

1. Install Street Scene Signal® Mirrors assemblies to doors, following mirror installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehical. If any problems exist, repair before wiring Street Scene Signal® Mirrors.
3. Remove the kick panels.
4. Run the Red / Black wire from the mirror into the door and thru the door boot. Run the right wire under the dash across to the steering column.
5. Run the left wire in the same way to below the steering column.
6. Remove the phillips head screws securing the panel beneath the steering column. This will expose the bundle of wires.
7. Locate the solid " LIGHT BLUE " wire. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with a test light to verify that flashing turn signal is present. Label that wire as " Driver's Side Turn ". Locate the solid " DARK BLUE " wire and probe with test light. Activate the passenger side turn signal to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn ".
8. Make sure the harnesses are routed securly under the dash and enough slack is left for splicing.
9. Using the Quick Splice connector provided, splice the RED wire from the driver side harness into the " LIGHT BLUE " wire labeled " Driver's Side Turn ". Do not cut any wires when splicing, Splice the Red wire from the passenger side harness into the " DARK BLUE " wire labeled " Passenger Side Turn ".
10. Strip and twist together the ends of the " BLACK " wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal frame work of the vehicle.
11. Activate each turn - signal to verify that the Street Scene Signal® Mirrors are working. Replace all the lower dash panels removed.
12. Re-install door panels.

1/11/01 Connecting Signal® Mirrors
1988 - 1998 Chevy / GMC CK trucks
1992 - 1999 Suburbans / Tahoes / Yukons & Crew Cab Dually's