



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-70346

2008-2013 INFINITI G37  
COUPE FRONT SPLITTER  
FOR STOCK FASCIA  
URETHANE

### INSTALLATION INSTRUCTIONS


**NOTE:** Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

**VERY IMPORTANT!** Read and understand all directions and check the following parts list before starting installation.


PARTS LIST					
1	Front Splitter	1	Instruction Sheet	8 FT.	1/2" Two Sided Tape # 75344
8	#10x1" Pan Head Screws #49156			2	Stainless Steel Turnbuckles
2 PKGS	3M Adhesion Promoter			8	1/4" SS Machine Screws

TOOL LIST	
Drill Motor, Drill Bits.	

1. On the back of the splitter there is an indentation. This is where you will apply the double sided tape. This surface has to be **CLEAN** and **DRY** for the tape to properly adhere. The surface of the vehicle should also be cleaned for proper adhesion. After cleaning use a 3M promoter on both surfaces.
2. When applying tape, make sure that the tape is smooth and wrinkle free. It is best to use 3 or 4 different pieces on long sections rather than 1 piece.
3. It is best to hold up the splitter to the vehicle so you can mark the area that needs to be prepped. See **(FIG 1)**.



4. Place the splitter **GENTLY** on the vehicle and make sure you have it positioned correctly. It is good to have a friend help with this. If adhesion promoter was used you will **NOT** get a second chance!
5. Now pull back approx 1 inch of protective covering on tape from each end. Make sure the film is sticking out. While holding it in position, pull the tabs you created while applying light downward pressure. See **(FIG 2)**.



6. Continue this taking care not to tear off the tabs by pulling to hard. After all the film is removed, apply firm pressure all around to insure the tape has bonded properly.
7. Next you will need to secure the underside of the splitter. Use the self tapping screws space out evenly as seen in **(FIG 3)**. It is recommended that you drill pilots holes in the locations you will be securing the splitter.

